



**⚠ WARNING**

- Never exceed the working load limit of rope.
- Attachments must have at least same working load limit as the rope used.
- Keep out from under a raised load.
- Destroy, rather than discard, rope to be retired.
- Inspect rope frequently; store properly.
- Avoid overheating, shock loads, chemicals, rust and abrasion.
- Always destroy any product that shows wear, tearing or knots!

**MANILA ROPE**

- 3 STRAND POLY WRAPPED COILS.
- Block and tackle assemblies available in manila or nylon rope.

Indusco Part #	Size	Length	Approx. Weight per Coil	Working Load Limit
721 00051	1/4	600	12	108
721 00056	1/4	1250	25	108
721 00061	1/4	2500	50	108
721 00066	5/16	185	25	180
721 99999	5/16	1750	50	180
721 00076	3/8	100	4	243
721 00081	3/8	200	8	243
721 00086	3/8	300	12	243
721 00091	3/8	600	25	243
721 00096	3/8	1200	80	243
721 00101	1/2	100	8	477
721 00106	1/2	200	15	477
721 00111	1/2	300	23	477
721 00116	1/2	600	45	477
721 00121	1/2	1200	90	477
721 00126	5/8	100	13	792
721 00131	5/8	200	27	792
721 00136	5/8	300	40	792
721 00141	5/8	600	80	792
721 00146	5/8	1200	160	792
721 00151	3/4	100	17	992
721 00156	3/4	200	34	992
721 00161	3/4	300	51	992
721 00166	3/4	600	100	992
721 00171	3/4	1200	200	992
721 00176	7/8	600	135	1386
721 00186	1	100	27	1620
721 00191	1	200	54	1620
721 00196	1	300	81	1620
721 00201	1	600	162	1620
721 00206	1	1200	324	1620
721 00216	1-1/4	600	251	2430
721 00221	1-1/2	600	360	3330
721 00226	2	200	216	5580
721 00231	2	600	648	5580

**⚠ WARNING** Never exceed working load limit.

CALL **1-800-727-0665** TO PLACE AN ORDER  
[www.induscowirerope.com](http://www.induscowirerope.com)

See pages 4 - 10 for important safety information.  
 All measurements/units listed are in inches/pounds unless otherwise noted.